



## Wipe out Biofilms with PCS 5000

PCS offers two processes using PCS 5000 wipes to address accumulated fixed organic soils from surfaces.

1: Applied from the container to the surface.

2: Add one cloth per liter of water used. Cloth or cloths provide a small amount of sodium hypochlorite in rinsing solution.

They are used to remove the residues from fixed and attached bioburden that have been damaged and dislodged from the application of PCS 5000.

### Procedure

- Remove visible soil first
- Apply PCS 5000 solution with pre moistened cloth to surface keeping wet for 5 minutes
- Take a cloth from diluted solution and squeeze excess liquid from cloth and wipe over surfaces treated with PCS 5000.